



WERKA PRO

Notice d'installation

(Installation instructions / Instrucciones de instalación / Anleitung zur Installation / Istruzioni per l'installazione / Installatie-instructies)

Parasol déporté Ø3m crème WERKAPRO

(WERKAPRO offset parasol Ø3m cream / Sombriilla Offset Ø3m crema WERKAPRO / Freistehender Sonnenschirm Ø3m cremefarben WERKAPRO / Ombrellone offset Ø3m crema WERKAPRO / Offset parasol Ø3m crème WERKAPRO)

Réf 15870



Importé par Provence Outillage www.werkapro.fr
420, route de Robion 84300 Les Taillades France
Tél : 04 90 78 09 61 (Lundi au Vendredi 9 à 17 heures)



A		1	F		4
B		1	G		4
C		1	H		1
D		1			
E		2			